

CAMLINK

BETA

BATTERY CHARGER

Operating Instructions

1. Insert 1-2 pieces of AA or 1-2 pieces of AAA rechargeable Ni-MH / Ni-Cd battery into the battery compartment, ensuring correct polarity (+ and -) in accordance with the signs in the battery compartment.
2. Plug the charger into a household electric outlet. The LED will light up instantly to indicate correct charging. The two LEDs will not switch off when the batteries are fully charged.
3. Batteries should be charged for the times indicated in the table below, manually controlling the charging time.
4. Begin again at Step 1 to charge the next set of batteries

Charging Time

Type	Capacity	Chemistry	Manually Time For
AA	700 mAh	Ni-Cd	4 hours
AA	1300 mAh	Ni-MH	8 hours
AA	2100 mAh	Ni-MH	13 hours
AA	2500 mAh	Ni-MH	15 hours
AA	2700 mAh	Ni-MH	16.5 hours
AAA	600 mAh	Ni-MH	8 hours
AAA	800 mAh	Ni-MH	11 hours
AAA	1000 mAh	Ni-MH	14 hours

Charge time will vary depending upon the brand, capacity and condition of the batteries being charged.

Important Safety Instructions

1. Before charging, read instructions.
2. This charger is intended for use with Nickel-metal-hydride and Nickel-Cadmium rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and/or damage to the charger.
3. Recharge only one type of battery (Ni-MH or Ni-Cd) at a time.
4. Do not charge longer than the time indicated in the table above. Overcharging may cause damage to the charger and/or batteries.
5. Do not expose charger to rain or moisture. For indoor use only.
6. Remove from the mains supply when not in use.
7. Do not operate the charger if it has been subjected to shock or damage. Take it to a qualified serviceman for repair.
8. Do not disassemble the charger. Incorrect reassembly may result in a risk of electric shock or fire.
9. Unplug the charger from the mains outlet before attempting any maintenance or cleaning. Use a damp cloth to clean the surface, do not immerse into water.
10. The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
11. Before scrapping your charger, remove the batteries from the unit and ensure that they are disposed of safely.